

Panasonic

Variable Speed AC Motor Drive

DV707H SERIES

Table of contents

Chapter 1-Pre-installation	1	Chapter 6-Parameter	29
1.0 Caution		6.0 Parameter list	
1.1 Installation		6.1 Parameter functions	
		(Factory adjustable settings)	
Chapter 2-Name plate data	3	6.2 Parameter functions	
		(Non factory settings)	
2.0 Name plate identification		Chapter 7-Maintenance and inspection ..	41
2.1 Model identification		7.0 Note on maintenance	
2.2 Construction		and inspection	
Chapter 3-Specification	6	7.1 Inspection cycle	
		7.2 Megger test	
3.0 Standard specifications		7.3 Selection of meters	
3.1 Dimensions		Chapter 8-Troubleshooting	43
Chapter 4-Installation	9		
		8.0 Cause of trouble and check	
4.0 Safety caution		8.1 Protective functions	
4.1 Proper use of the Inverter		8.2 Measures to eliminate	
4.2 Wiring		external noise	
4.3 Terminal functions			
4.4 Standard wiring diagram			
4.5 Wiring selection			
Chapter 5-Operation	16		
5.0 Prior to operation			
5.1 How to operate			
5.2 Operation panel			
5.3 Trial operation			
5.4 Remote operation panel			
5.5 Parameter selection			
5.6 Operating functions			
5.7 Operation mode			
5.8 Monitoring			


Chapter 1-Pre-installation

1.0 Caution

- Please handle the Inverter carefully.
- Please do not apply a force to a terminal cover.


1.1 Installation

- Please install vertically and allow enough open space for a better ventilation.




- Note) ◇ Please use a mounting plate of the Inverter base with bolt or screw.
◇ Use M5 size bolt or screw.
◇ Please refer the mounting dimension to our drawing.
◇ Please mount on an incombustible material(metal) for a better heat dissipation.


- Please avoid high temperature, humidity, or dusty place.




- Please make sure ambient temperature is within -10°C and $+50^{\circ}\text{C}$.
In case, room temperature is over $+40^{\circ}\text{C}$ please take off the ventilation cover and bushing.




- Please avoid the direct sunlight.




- Please do not subject the Inverter to corrosive gas or oil.



- This Inverter is not Water Proof. Please avoid using outdoors.



- Please install at a stable location, or avoid using the Inverter continuously in the place with the vibration near the resonance frequency.




2.2 Construction

●DV707H750~3700

■A, B type (W/ operation panel)


■C, D type (W/ interface panel)



* Ventilation covers are installed when shipping the Inverter.

In case, room temperature is over 40°C, please take off the ventilation cover and bushing.

<<when the terminal cover is taken out>>



Chapter 3-Specification

3.0 Standard specifications

Type designation* ¹		DV707H750 A, B, C, D	DV707H1500 A, B, C, D	DV707H2200 A, B, C, D	DV707H3700 A, B, C, D
Output ratings	Applied motor (kW)* ²	0.75	1.5	2.2	3.7
	Rated capacity (kVA)* ³	1.9	2.8	4.2	6.9
	Rated output current (A)	2.5	3.7	5.5	9.0
	Rated output voltage* ⁴	3 phase, AC 380~440V			
Power source	Voltage/Frequency	3 phase, AC 380~440V 50/60Hz			
	Allowable voltage range	± 10%			
	Allowable frequency range	± 5%			
Control spec.	Control system	Sine wave PWM			
	Output frequency range	0.5~400Hz (Start/Stop from 0.5Hz)			
	Frequency accuracy	± 0.5% (at 25°C ± 10°C)			
	Freq. setting resolution	<digital>:0.1Hz <analog>:Frequency range/1000Hz(Min.:0.05Hz)			
	Frequency command signal	DC 0~+5V, 0~+10V, 4~20mA			
	V/F pattern	Base frequency: 30~400Hz(1Hz step), Max.output volt.: 0~100% Torque boost, Squared reduced torque pattern, 2nd.V/F pattern			
	Over load capacity	150% for 1min.			
	Regenerative brake torque	Type A, C	20%		
		Type B, D	150% or more	100% or more	100% or more
	DC dynamic brake	Free setting of Starting frequency, Brake time, Brake torque			
	Acceleration/ deceleration time	0~3600secs(0~3secs:0.02secs step, 3~10secs:0.1secs step, 10~3600secs:1sec step) Time to change up to 50Hz. Up to 4th.accel./decel.time. Linear and 2-"S" shaped acceleration/deceleration.			
	Logging frequency range	0~30Hz			
	Operation mode	2-speed mode, 4-speed mode, 8-speed mode, 16-speed mode			
	Others	Selectable retry function, Parameter lock, Automatic/Manual torque boost, Slip freq.compensation control			
Protective function		Undervoltage protection, Overvoltage protection, Overcurrent protection, Overload shutoff(Electronic thermal), Overload limit(current limit), Instantaneous power failure protection, Overvoltage stall prevention, Overcurrent stall prevention, Auto restart prevention, Self-diagnosis trip (memorizes causes of last 5 trips)			
Ambient	Temperature	-10°C~+50°C In case, room temperature is over 40°C, please take off the ventilation cover and bushing.			
	Relative humidity	Max. 90%RH (non-condensing)			
	Atmosphere	Indoors (to be free from corrosive gas, dust)			
	Altitude	Up to 1000m without de-rating			
	Vibration	5.9m/s ² (0.6G) or less (10~60Hz)			
Enclosures		Enclosed type* ⁵			
Cooling method		Free cooling		Fan cooling	
Mass (kg)		2.9	2.9	2.9	

*1) Please refer to Chapter 「2.0 Name plate identification」 for distinction.

*2) Please select the proper motor which does not exceed the rating of the Inverter.


*3) Rated capacity is a value at 440V of the rated output voltage.

*4) Please note that the output voltage of the Inverter will not exceed the power source voltage.


*5) Except the connector of the interface panel.

3.1 Dimensions (in mm)


- DV707H7500A, B
- DV707H15000A, B
- DV707H22000A, B
- DV707H37000A, B



- DV707H7500C, D
- DV707H15000C, D
- DV707H22000C, D
- DV707H37000C, D




- DV707H5500A, B
- DV707H7500A, B
- DV707H11kWA, B



- DV707H5500C, D
- DV707H7500C, D
- DV707H11kWC, D

※取り付けネジはM5を
使用してください。




4.1 Proper use of the Inverter

Misuse of the Inverter leads to a wrong operation or sometimes results in damage to the Inverter. Please read the following for proper use of the Inverter.

- Please do not input higher voltage than rating to the line terminals(L1,L2,L3). Please do not connect the line to other than 「L1」,「L2」 and 「L3」 terminals. (refer to Chapter 「3.0 Standard specifications」)
- Please use the power supply of capacity from 150% of the capacity of the Inverter to 500kVA. When the power supply of capacity which exceeds 500kVA is used and the Phase-advance capacitor of the power supply is switched, please set up the suitable power factor correction Reactor for the capacity of the Inverter on the line side of the Inverter.
- Higher ambient temperature may influence the life of the Inverter. Please try to use at lower temperature as much as possible.
- Please do not install Electromagnetic Contactor between the motor and the Inverter in order start/stop the motor. Please start/stop the motor with 「RUN」/「STOP」 switches on the operation panel or with input terminals of the Inverter (「I1」, 「I2」).
- Please do not connect Phase-advance capacitor to output side of the Inverter.
- When you perform 「Megger test」, please follow procedure as described in Chapter 「7.2 Megger test」.
- Please avoid an overload operation which exceeds the capacity of the Inverter.
- Please ensure the sensitivity current is 30mA or more on the line side of the Inverter if you use an Earth Leakage Circuit Breaker.

Note

- Ambient temperature may affect the life of the Inverter. Please make sure that the ambient temperature will not exceed allowable temperature.
- Make sure that temperature at marked place will not exceed allowable temperature.



《 Allowable temperature 》

- 10℃ ~+40℃ : with ventilation covers & bushing(Factory setting) : DV707H750~3700
- 10℃ ~+50℃ : without ventilation covers & bushing : DV707H750~3700
- 10℃ ~+50℃ : without ventilation covers & bushing(Factory setting) : DV707H5500~11kW

4.3 Terminal functions

<Control circuit>

NC	COM2	NO	5V	G	I1	I3	I5	G
COM1	O1	O2	FIN2	FIN1	FOUT	I2	I4	I6

<Main circuit>

●DV707H750~3700

Line

Motor

PE	L1	L2	L3	U	V	W	PE
----	----	----	----	---	---	---	----

●DV707H5500~11kW

Line

Motor

L1	L2	L3	U	V	W	PE
----	----	----	---	---	---	----



- ◆ Input terminals from 「I1」 to 「I6」 are pulled up from +5V by 4.7KΩ. You can control with a contact or an open collector output.
- ◆ Please do not touch the control circuit terminals while the power is on. This may cause malfunction due to a static electricity.




Input/output terminal function

Symbol/terminal title	Description															
L 1, L 2, L 3 /Line input terminals	Connect to the power source of AC 380~440V, 50/60Hz.															
U, V, W /Motor output terminals	Connect to the 3-phase induction motor.															
PE /Ground terminal	Frame ground:Please ground W/O fail(10Ω or less, φ1.6mm or larger).															
5.V /Freq. setting source	DC +5V is applied.															
FIN1, FIN2 /Analog frequency setting input	You can make a frequency setting with the input of DC 0~5V or DC 0~10V between 「FIN1」 and 「G」. This is valid when 「17 Frequency command selection」 is set to 0-5 or 0-10 . You can make a frequency setting with the input of DC 4~20mA between 「FIN2」 and 「G」. If you command both 「FIN1」 and 「FIN2」, lager value is valid.															
G /Control signal ground	Common for the control signal.															
FOUT /Frequency meter output	Outputs the voltage in proportion to the output frequency between 「FOUT」 and 「G」. Connect the frequency meter of full scale with 100μA. You can output the pulse which synchronizes with the output frequency by changing 「54 FOUT selection」. Output impedance : 390kΩ															
I 1 /Forward run command	● 「I1」 - 「G」/short : Forward run, 「I1」 - 「G」/open : Stop															
I 2 /Reverse run command	● 「I2」 - 「G」/short : Reverse run, 「I2」 - 「G」/open : Stop You can make 「I1」 as run/stop and 「I2」 as forward/reverse command by changing 「45 I1・I2 function selection」.															
I 3, I 4 /Selectable function(1) - Jogging command - Freq. setting select	You can select following functions per 「5.7 Operation mode」 : <table><tr><td>Operation mode</td><td>I 3</td><td>I 4</td><td>I 5</td><td>I 6</td></tr><tr><td>2-speed mode</td><td>Fwd. jogging</td><td>Rev. jogging</td><td colspan="2" rowspan="4">Free-run command, Outer trip command, 2nd. accel./decel. time, Trip reset</td></tr><tr><td>4-speed mode</td><td colspan="2" rowspan="3">Frequency setting selection</td></tr><tr><td>8-speed mode</td></tr><tr><td>16-speed mode</td></tr></table>	Operation mode	I 3	I 4	I 5	I 6	2-speed mode	Fwd. jogging	Rev. jogging	Free-run command, Outer trip command, 2nd. accel./decel. time, Trip reset		4-speed mode	Frequency setting selection		8-speed mode	16-speed mode
Operation mode	I 3	I 4	I 5	I 6												
2-speed mode	Fwd. jogging	Rev. jogging	Free-run command, Outer trip command, 2nd. accel./decel. time, Trip reset													
4-speed mode	Frequency setting selection															
8-speed mode																
16-speed mode																
I 5, I 6 /Selectable function(2) - Free-run command - 2nd. accel./decel. time - Outer trip - Freq. setting select																
G /Control signal ground	Common for the control signal.															
O 1, O 2 (Collector) COM1 (Emitter) /Output signal	Open collector output terminals(does not hold when the power is off.). You can select the function through 「53 Output signal① selection」 or 「52 Output signal② selection」. Factory setting: 「O1」 is trip signal. Ic max. = 50mA, 「O2」 is reach signal. Vce max. = DC 24V															
NC, NO、COM2	RY output terminals(does not hold when the power is off.). You can select the function through 「53 Output signal selection」 Signal off : 「NO」-「COM2」→OPEN. 「NC」-「COM2」→CLOSE. Signal on : 「NO」-「COM2」→CLOSE. 「NC」-「COM2」→OPEN AC250V 5A(DC30V 5A)															

4.4 Standard wiring diagram

<< At factory setting >>



* Factory setting

Chapter 5-Operation

5.0 Prior to operation

After you install and finish wiring, please check the following points before the operation.

- (1) Right wiring ? (Especially line input terminals 「L1」, 「L2」 and 「L3」, and output terminals, 「U」, 「V」 and 「W」)
- (2) Right input ? (3 phase, 380~440V, 50/60Hz)
- (3) Any short circuit portion ?
- (4) Any loose screw or termination ?
- (5) Any short circuit or grounding at load ?

5.1 How to operate

You can enter the frequency command and the run command by the following 6 ways through the operation panel or the terminal board;

	Frequency command		Run command		Note
	panel	board 「FIN1」* ² or 「FIN2」* ³	panel	board 「FIN1」 or 「FIN2」	
1	○		○ * ¹	○ * ¹	【Factory setting】 Change parameter, 「P15」 Run command selection」 or 「P17」 Frequency command selection」 (Please refer to Chapter 「6.1 Parameter functions」)
2		○	○ * ¹	○ * ¹	
3	○		○		
4		○	○		
5	○			○	
6		○		○	

- *1) The command through the terminal board is given a priority when the command is entered through both the panel and the terminal board. 「RUN」 switch is valid only when both 「I1」, forward run switch and 「I2」, reverse run switch is 「OFF」. If either or both of 「I1」 or/and 「I2」 of the terminal board is turned on, the command through the run switch of the panel will be cancelled.
- *2) 「FIN1」 terminal is the voltage command only.
- *3) 「FIN2」 terminal is the current command only.

☆ You can operate following additional functions through 「I3」~「I6」;

- Multi-speed operation up to 16 speeds
- Forward/reverse jogging
- Free-run command
- Acceleration/deceleration time selection up to 4
- Trip command
- Trip reset command

5.3 Trial operation

(1) For safety purpose, please proceed as follows;

- ① Make the motor operate alone.
- ② Turn all input to the terminal board to 「OFF」(open).
- ③ Turn the external potentiometer to the minimum.

(2) Then turn on the power (turn on the NFB 「Non-Fuse Breaker」 and the MC 「Magnetic Contactor」 at input side of the Inverter) and check the following;

Operation	Operation panel		Note
	SW	4-digit LED	
① Power on			- Monitor mode on turning the power on. (displays the output frequency)
② Set the frequency	- Push ,		- Displays 0-speed frequency. (Factory setting is 0.0Hz) (returns to the monitor mode if you do not operate SW for more than 3secs. In this case, push ,)
	- Set the frequency with ,		- Set 0-speed to 60.0Hz
③ Return to monitor mode			- Returns to the monitor mode if you do not operate SW for more than 3secs.
④ Run command	- Push		- Varies gradually.
⑤ Stop command	- Push		- Varies gradually.


〈 Check point at trial operation 〉

- ① Does the motor run smoothly ? Any abnormal noise or vibration ?
- ② Is acceleration/deceleration smooth ?
- ③ Is rotational direction of the motor correct ?

☆ If the Inverter trips or shows any malfunction, please refer to Chapter 「8 Troubleshooting」.
When the Inverter trips, cause of the trip will be indicated on 4-digit LED of the panel, and the motor becomes 「Free-run」. Please refer to Chapter 「5.8 Monitoring」 for display.

(2) Connection

Plug the one side of the connecting cable(option) into the connector of the Inverter and the other end into the connector of the remote control panel.




Inverter
(C Dtype)

Remote Control Panel
DVOP037

When you unplug, pull out while pushing the side of the the connector portion.

Please turn off the power to the Inverter when you plug-in or unplug.

(3) Composition



Front side consists of 4-digit LED **8.8.8.8**, **MODE** switch, setting switches **△** **▽**, run switch **RUN** and stop switch **STOP**. You can run/stop, confirm/change the parameters, Displays the Inverter's condition (output frequency, preset frequency and malfunction) and release the trip. (Please refer Chapter 「5.2 Operation panel」)

Back side consists of the connector 「CN」 and dip switch 「DSW」 with which you can prohibit the functions of the switches on the front side. Please follow the below when you want to prohibit the functions of the switches on the front side.

Dip switch	Title	Function	Factory setting
DSW-1	Parameter change prohibition switch	MODE and △ ▽ switch becomes void with this switch.	「ON」
DSW-2	Run/stop command prohibition switch	Run/stop switches becomes void with this switch 「OFF」.	「ON」

(2) Parameter selecting examples

■ How to set acceleration time.

<e.g.> Set 「21 Acceleration time」 to 1.0sec.

Operation	SW	4-digit LED	Note
① Power on		<u>00</u>	Monitor Mode
② Call for 「 <u>21</u> Acceleration time」	Push MODE . Set <u>21</u> with △ .	<u>00</u> <u>21</u>	Displays the parameter number. (returns to monitor mode if you do not operate SW for more than 3secs. In this case, please push MODE again.) 「 <u>21</u> Acceleration time」
③ Set to 1.0sec.	Push MODE . Set <u>1</u> with ▽ .	<u>5.0</u> <u>1.0</u>	Factory setting is <u>5secs.</u> Set 「Acceleration time」 to <u>1.0sec.</u>
④ Returns to monitor mode	Push MODE .	<u>21</u> <u>00</u>	Displays the parameter number. Returns to monitor mode in 3secs.

■ How to set a frequency with an external potentiometer.

<e.g.> Set 「17 Frequency command selection」 to 0-5 .

Operation	SW	4-digit LED	Note
① Power on		<u>00</u>	Monitor mode
② Call for 「 <u>17</u> Freq. command selection」	Push MODE . Set <u>17</u> with △ .	<u>00</u> <u>17</u>	Displays the parameter number. (returns to monitor mode if you do not operate SW for more than 3secs. In this case, please push MODE again.) 「 <u>17</u> Frequency command selection」
③ Set to 「0~5V」	Push MODE . Push △ . Push MODE . Memorize. *1	<u>PnL</u> <u>0-5</u> <u>17</u> <u>CAU</u> (trip)	Factory setting is operation panel Set 「Frequency command selection」 to 「0~5V」. Displays the parameter number. Trips for safety.
④ Release the trip*2	Push both △ & ▽	<u>00</u>	Monitor mode

*1) Changed parameter will be stored by pushing **△** or **▽** to move the parameter number or by returning to a monitor mode without touching SW for about 3secs.

*2) You cannot release the trip with **△** & **▽** if you push **MODE** before the trip release (this leads to show the trip factor). In this case, please release the trip by returning to a present trip factor mode. (refer to Chapter 「5.8 Monitoring」)

5.6 Operating functions

DV707H Series have the following operating functions. You can command through the switches on the operation panel or the terminal board.

Function	Contents
Normal operation	<ul style="list-style-type: none"> ■ Normal operating function with acceleration/deceleration time. ■ The Inverter makes soft start by shorting the terminals 「I1」-「G」(for forward run), 「I2」-「G」(for reverse run). ■ You can operate multi-speed(up to 16 speeds) with the frequency setting terminals. ■ You can set acceleration/deceleration time to 0~3600secs independently to each other. *1
Jogging operation	<ul style="list-style-type: none"> ■ Operating function with 0(zero)sec. acceleration/deceleration time. Useful for positioning. ■ Please select 「Operation Mode」*2 to 2-speed mode for this function. ■ The Inverter outputs 「Jogging frequency」 by shorting the terminals 「I3」-「G」(for forward jogging), 「I4」-「G」(for reverse jogging). ■ You can shift from normal operation to jogging or jogging to normal operation. ■ Jogging frequency can be set within 0~30Hz range, but if this is too high, the Inverter may trip due to an overcurrent. *3
Free-run stop	<ul style="list-style-type: none"> ■ The Inverter shuts off the output voltage to the motor. Useful for applying mechanical brake. Please note that the output terminals to the motor (U,V,W) are not insulated during a free-run stop. Please be careful for electrical shock.
DC dynamic brake *4	<ul style="list-style-type: none"> ■ Braking function by applying DC to the motor while the Inverter shifts from the operation to stop mode. If you enter the forward/reverse run command or the jogging command while the DC dynamic brake is working, the Inverter will stop braking and starts the instructed operation mode.
Positioning DC brake	<ul style="list-style-type: none"> ■ If you give a stop command during the normal operation, the Inverter starts braking and soft stop when the output frequency becomes 3Hz(changeable by parameter). ■ If you make preset frequency to 0(zero)Hz, a brake starts at an output frequency of 1Hz or lower. ■ You can set torque and time by the parameter.
Immediate DC brake (Full-range)	<ul style="list-style-type: none"> ■ Brake starts immediately after you give a stop command during a normal operation. (without making a soft stop) ■ You can set torque and time by the parameter. ■ Braking time to stop is 2 times that of 「Positioning DC brake mode」.

*1) Time to change up to 50Hz. Please refer to Chapter 「5.2 Operation panel」 how to set a acceleration/deceleration time.

*2) Please refer to Chapter 「5.7 Operation mode」.

*3) Please refer to Chapter 「5.2 Operation panel」 how to set a jogging frequency.

*4) Please refer to Chapter 「5.2 Operation panel」 how to set a brake mode selection.

5.7 Operation mode

DV707H Series have 4 operation modes. You can select a mode by 「18 Operation mode selection」(refer to Chapter 「6.1 Parameter functions」).

Operation mode	Terminal function						Value of 「18 Operation mode selection」
	I 1	I 2	I 3	I 4	I 5 *1	I 6 *1	
2-speed mode	Forward run	Reverse run	Forward jogging	Reverse jogging	- Free-run - Trip - 2nd. accel./ decel. time - Trip reset	- Free-run - Trip - 2nd. accel./ decel. time - Trip reset	2
4-speed mode	Forward run	Reverse run	Frequency setting selection		- Free-run - Trip - 2nd. accel./ decel. time - Trip reset	- Free-run - Trip - 2nd. accel./ decel. time - Trip reset	4 Factory setting
8-speed mode	Forward run	Reverse run	Frequency setting selection			- Free-run - Trip - 2nd. accel./ decel. time - Trip reset	8
16-speed mode	Forward run	Reverse run	Frequency setting selection				16

*1) You can select by 「47 I5 function selection」 or 「48 I6 function selection」.

☆ You can operate multi-speed(as below) by open/short the frequency setting terminals. When all terminal is open, 0-speed frequency will be selected and you can set by the parameter 「00 Preset frequency(0-speed)」 or by an external potentiometer. (select a parameter setting or an outer setting of 0-speed frequency by 「17 Frequency command selection」)

< Frequency setting selection at 4-speed mode(Factory setting) > *2

between 「I3」 and 「G」	between 「I4」 and 「G」	Frequency setting
open	open	0-speed freq.
short	open	1st. speed freq.
open	short	2nd. speed freq.
short	short	3rd. speed freq.

*2) Please refer to Chapter 「4.3 Terminal functions」 for a frequency setting selection at 8-speed mode or 16-speed mode.

5.8 Monitoring

(1) Frequency monitoring

The output frequency is always displayed when you turn on the power and run. When in parameter selection mode, the display will automatically return to the output frequency display if none of the panel switches are touched for more than 3secs.

You can display the preset frequency by selecting parameter [50 Monitor mode selection]).

(2) Warning/Malfunction monitoring

When the Inverter detects warning or trip, this will be displayed on 4-digit LED. This display is given the first priority. (refer to Chapter [8.1 Protective functions])

Alarm/ Fault	4-digit LED	Content
Alarm		Lack of input voltage
Alarm		Reverse run prevention
Alarm		Automatic restart prevention
Fault		Overcurrent trip
Fault		Overcurrent trip at accel.
Fault		Overcurrent trip at decel.
Fault		Overvoltage trip
Fault		Outer trip
Fault		Electronic thermal
Fault		CPU error
Alarm		Overvoltage trip on the power on

Alarm/ Fault	4-digit LED	Content
Alarm		Change/store following parameters [15 Run command selection] [17 Frequency command selection] [18 Operation mode selection] [38 2nd. V/F type selection] [45 Multi-speed input selection] [46 11-12 function selection] [47 15 function selection] [48 16 function selection] [69 Reverse run prevention] [70 Automatic restart prevention] [71 Retry selection] [73 Frequency at 5V input] [74 Frequency at 0V input]
Alarm		End of parameter initialization *1.
Alarm		End of clearance of trip causes *2

*1) Refer to [86 Parameter initialization].

*2) Refer to [80 Trip causes clearance].

(3) Cause of past trip monitoring

You can confirm causes of up to the last 5 trips from [81 Trip cause ①] to [85 Trip Cause ⑤].

You can confirm per the following method while the Inverter trips:

Operation	Operation panel		Note
	SW	4-digit LED	
Trip occurs.			<e.g.> Overcurrent trip
① Confirm cause of the last trip.	Push [MODE].		[81 Trip cause ①]
	Push [MODE].		For example, cause of the last trip is overvoltage.
② Confirm cause of the 2nd. latest trip.	Push [MODE].		Displays parameter number again.
	Push [Δ].		[82 Trip cause ②]
	Push [MODE].		Displays cause of the 2nd. latest trip(blank if none).
③ Confirm cause of the 3rd. ~5th. latest trip.	Repeat ② procedure.		
④ Return to the present trip display mode. *1	Push [MODE].		Displays the parameter number.
			Returns to monitor mode in 3secs.

*1) You can return to the present trip display mode in about 3secs. If you do not operate SW while the parameter number(81~85) is displayed. Please release the trip with both [Δ] and [▽] while the present trip display is on.

No.	Parameter title	Specification				Order of display
		Adjustable range	Min. unit	Factory set	User setting	
04	4th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		1 6
05	5th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		1 7
06	6th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		1 8
07	7th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		1 9
08	8th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 0
09	9th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 1
10	10th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 2
11	11th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 3
12	12th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 4
13	13th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 5
14	14th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 6
15	15th. speed freq.	0, 0.5~Upper limit freq.	0.1Hz	0Hz		2 7
23	3rd. accel. time	0~3600secs ~ 3secs : 0.02secs step 3secs~10secs : 0.1secs step 10secs~ : 1sec. step		5secs		2 8
33	3rd. decel. time			5secs		2 9
24	4th. accel. time			5secs		3 0
34	4th. decel. time			5secs		3 1
25	DC brake torque	0~100	2	76(50*1)		3 2
26	DC brake time selection	0~3secs : <input type="text" value="POS"/> 0~6secs : <input type="text" value="-POS"/>	0.05secs 0.1 secs	0.5secs		3 3
27	DC brake type selection	<input type="text" value="-POS"/> Immediate <input type="text" value="POS"/> Positioning		<input type="text" value="POS"/>		3 4
28	Start-up DC brake time	0~3secs	0.05secs	0(No active)		3 5
29	DC brake starting freq.	0.5~400Hz	0.1Hz	3Hz		3 6
36	Maximum output voltage	0~100%	1%	100%		3 7
37	V/F pattern	1.0~2.0(squared)	0.1	1.0		3 8
38	2nd. V/F type selection	<input type="text" value="NO"/> Normal <input type="text" value="UP"/> Upper <input type="text" value="LD"/> Lower		<input type="text" value="NO"/>		3 9
39	2nd. base freq.	30~400Hz	1Hz	60Hz		4 0
40	2nd. torque boost	0~100	2	0		4 1
41	Jump freq. ①-A	0, 0.5~400Hz	0.1Hz	0Hz		4 2
42	Jump freq. ①-B	0, 0.5~400Hz	0.1Hz	0Hz		4 3
43	Jump freq. ②-A	0.5~400Hz	0.1Hz	60Hz		4 4
44	Jump freq. ②-B	0.5~400Hz	0.1Hz	60Hz		4 5
45	Multi-speed input selection	<input type="text" value="1b 1F"/> 1 bit <input type="text" value="b 1n"/> Binary		<input type="text" value="b 1n"/>		4 6

*1) DV707H1500, DV707H2200, DV707H3700, DV707H5500, DV707H11kW only.

No.	Parameter title	Specification				Order of display
		Adjustable range	Min. unit	Factory set	User setting	
67	Accord detect width	0~400Hz	0.1Hz	3Hz		6 6
68	Reduced frequency at IPF	0~400Hz	0.1Hz	3Hz		6 7
69	Reverse run prevention	<input type="checkbox"/> Fwd./Rev. <input checked="" type="checkbox"/> YES Fwd. only		<input type="checkbox"/>		6 8
70	Automatic restart prevention	<input type="checkbox"/> Auto-restart <input checked="" type="checkbox"/> YES Manual-restart		<input type="checkbox"/>		6 9
71	Retry selection	<input type="checkbox"/> No retry <input type="checkbox"/> 1 ~ <input type="checkbox"/> 4 Retry		<input type="checkbox"/>		7 0
72	Retry starting time	0~120secs	2secs	4secs		7 1
73	Freq. at 5V input	0, 0.5~400Hz	0.1Hz	60Hz		7 2
74	Freq. at 0V input	0, 0.5~400Hz	0.1Hz	0Hz		7 3
75	Upper limit frequency	Lower limit freq. ~400Hz	0.1Hz	60Hz		7 4
76	Lower limit frequency	0, 0.5~Upper limit freq.	0.1Hz	0Hz		7 5
77	Retry after overvoltage trip on power-on	<input type="checkbox"/> <input checked="" type="checkbox"/> YES		<input type="checkbox"/>		7 6
79	Electronic thermal	50~100%	5%	100%		7 7
80	Trip causes clearance	<input type="checkbox"/> <input checked="" type="checkbox"/> YES		<input type="checkbox"/>		7 8
81	Trip cause ①	Cause of the last trip	—	—		7 9
82	Trip cause ②	Cause of 2nd. latest trip	—	—		8 0
83	Trip cause ③	Cause of 3rd. latest trip	—	—		8 1
84	Trip cause ④	Cause of 4th. latest trip	—	—		8 2
85	Trip cause ⑤	Cause of 5th. latest trip	—	—		8 3
86	Parameter initialization	<input type="checkbox"/> <input checked="" type="checkbox"/> YES		<input type="checkbox"/>		8 4
87	Motor selection	<input type="checkbox"/> 4 P. 0.8 Applicable motor** Motor pole numbers		4poles Same as Inverter capacity**		8 5
88	Do not use.					
--	Parameter lock	<input type="checkbox"/> No lock. <input checked="" type="checkbox"/> ALL Lock all the parameter. <input type="checkbox"/> PART Page 1(one) lock.		<input type="checkbox"/>		—


Note)

*1 When you change/store the ☐ marked parameters, the Inverter trips for safety. Please release the trip to operate again.

*2 Applicable motor is represented as 0.8=0.75kW, 1.5=1.5kW, 2.2=2.2kW, 3.7=3.7kW, 5.5=5.5kW, 7.5=7.5kW, 11=11kW.

*3 Factory setting is the motor with the same capacity as the Inverter is preset.

No.	Parameter title	Description	Order of display
21	Acceleration time	You can adjust varying rate at acceleration/deceleration time. - Set with the time to change by 50Hz. - When you set 0sec., actual accel./decel. time becomes 0.05sec.	09
31	Deceleration time		10
22	2nd. accel. time	You can adjust varying rate at 2nd. acceleration/deceleration time. This is valid when 「47 15 function selection」 or 「48 16 function selection」 is set to <input type="checkbox"/> U- <input type="checkbox"/> D (2nd. acceleration/deceleration).	11
32	2nd. decel. time		12
20	Jogging frequency	You can adjust a frequency at jogging run.	13
30	Do not use.		14
35	Base frequency	You can adjust a base frequency (Maximum frequency at constant torque area) to any frequency between 30 and 400Hz.	15



*1) Factory setting

Note:

Above 15 parameters are adjustable at factory settings. Please set 「Number of selectable parameters」 before confirming/changing the parameters in the following pages.

6.2 Parameter functions(Non factory settings)

Note:



Please set 「Number of selectable parameters」 before confirming/changing the following parameters. (refer to Chapter 「5.5 Parameter selection」)

No.	Parameter title	Description	Order of display
04	4th. speed freq.	You can set 4th. ~15th. speed frequency when you select 8-speed, 16-speed operation mode at 「18 Operation mode selection」.	16
05	5th. speed freq.		17
06	6th. speed freq.		18
07	7th. speed freq.		19
08	8th. speed freq.		20
09	9th. speed freq.		21
10	10th. speed freq.		22
11	11th. speed freq.		23
12	12th. speed freq.		24
13	13th. speed freq.		25
14	14th. speed freq.		26
15	15th. speed freq.		27
23	3rd. accel. time	You can set varying rate at 3rd. /4th. acceleration/deceleration time. This is valid when both 「47 15 function selection」 and 「48 16 function selection」 is set to <input type="checkbox"/> U- <input type="checkbox"/> D . (2nd. acceleration/deceleration).	28
33	3rd. decel. time		29
24	4th. accel. time		30
34	4th. decel. time		31

*1) Factory setting

No.	Parameter title	Description	Order of display																																		
45	Multi-speed input selection	<p>You can set a selecting method of frequency at multi-speed operation</p> <ul style="list-style-type: none">● 1b 1f (1 bit) : 1 bit input You can select one frequency per corresponding terminal of 「Frequency setting selection terminal」. You can operate up to 3 speeds at 4-speed mode, 4 speeds at 8-speed mode and 5 speeds at 16-speed mode. <e.g.>at 16-speed mode <table><tr><th colspan="4">Input terminal</th><th rowspan="2">Freq. setting</th></tr><tr><th>I 3</th><th>I 4</th><th>I 5</th><th>I 6</th></tr><tr><td>open</td><td>open</td><td>open</td><td>open</td><td>0-speed freq.</td></tr><tr><td>short</td><td>×</td><td>×</td><td>×</td><td>1st. speed freq.</td></tr><tr><td>open</td><td>short</td><td>×</td><td>×</td><td>2nd. speed freq.</td></tr><tr><td>open</td><td>open</td><td>short</td><td>×</td><td>3rd. speed freq.</td></tr><tr><td>open</td><td>open</td><td>open</td><td>short</td><td>4th. speed freq.</td></tr></table> <p>- open/short represents the relation to 「G」 - × means 'don't care'</p> <ul style="list-style-type: none">● b 1n (Binary) : Binary input*1 You can select a frequency by interpreting 「Frequency setting selection terminal」 as binary digits.	Input terminal				Freq. setting	I 3	I 4	I 5	I 6	open	open	open	open	0-speed freq.	short	×	×	×	1st. speed freq.	open	short	×	×	2nd. speed freq.	open	open	short	×	3rd. speed freq.	open	open	open	short	4th. speed freq.	4 6
Input terminal				Freq. setting																																	
I 3	I 4	I 5	I 6																																		
open	open	open	open	0-speed freq.																																	
short	×	×	×	1st. speed freq.																																	
open	short	×	×	2nd. speed freq.																																	
open	open	short	×	3rd. speed freq.																																	
open	open	open	short	4th. speed freq.																																	
46	I1-I2 function selection	<p>You can select the function of 「I1」 and 「I2」 as follows;</p> <table><tr><th rowspan="2">Terminal Setting</th><th colspan="2">between 「I1」 and 「G」</th><th colspan="2">between 「I2」 and 「G」</th></tr><tr><th>short</th><th>open</th><th>short</th><th>open</th></tr><tr><td>F 5. r 5*1</td><td>Forward run</td><td>Stop</td><td>Reverse run</td><td>Stop</td></tr><tr><td>r 5. F r</td><td>Run</td><td>Stop</td><td>Reverse</td><td>Forward</td></tr></table> <p>(F 5. r 5 : Fwd. -Stop/Rev. -Stop r 5. F r : Run-Stop/Fwd. -Rev.)</p>	Terminal Setting	between 「I1」 and 「G」		between 「I2」 and 「G」		short	open	short	open	F 5. r 5 *1	Forward run	Stop	Reverse run	Stop	r 5. F r	Run	Stop	Reverse	Forward	4 7															
Terminal Setting	between 「I1」 and 「G」			between 「I2」 and 「G」																																	
	short	open	short	open																																	
F 5. r 5 *1	Forward run	Stop	Reverse run	Stop																																	
r 5. F r	Run	Stop	Reverse	Forward																																	
47	I5 function selection -Invalid at 8-speed mode, 16-speed mode	<p>You can select the function of 「I5」 and 「I6」 as follows;</p> <ul style="list-style-type: none">● F r E E short 「I5」(「I6」) & 「G」 → Free-run stop*1 (Free)● T H r short 「I5」(「I6」) & 「G」 → Trip command (Thermal)● U - d short 「I5」(「I6」) & 「G」 → 2nd. accel./decel. *1 (Up-Down)● r 5 F short 「I5」(「I6」) & 「G」 → Trip reset command (Reset) <p>- When you select T H r, short 「I5」(「I6」) & 「G」 in advance. - When you set both 47 and 48 to U - d, you can select 4 acceleration/deceleration times.</p> <table><tr><th>between 「I5」&「G」</th><th>between 「I6」&「G」</th><th>Accel./decel. setting</th></tr><tr><td>open</td><td>open</td><td>Accel./decel. time</td></tr><tr><td>short</td><td>open</td><td>2nd. accel./decel. time</td></tr><tr><td>open</td><td>short</td><td>3rd. accel./decel. time</td></tr><tr><td>short</td><td>short</td><td>4th. accel./decel. time</td></tr></table>	between 「I5」&「G」	between 「I6」&「G」	Accel./decel. setting	open	open	Accel./decel. time	short	open	2nd. accel./decel. time	open	short	3rd. accel./decel. time	short	short	4th. accel./decel. time	4 8																			
between 「I5」&「G」	between 「I6」&「G」	Accel./decel. setting																																			
open	open	Accel./decel. time																																			
short	open	2nd. accel./decel. time																																			
open	short	3rd. accel./decel. time																																			
short	short	4th. accel./decel. time																																			
48	I6 function selection -Invalid at 16-speed mode	<table><tr><th>between 「I5」&「G」</th><th>between 「I6」&「G」</th><th>Accel./decel. setting</th></tr><tr><td>open</td><td>open</td><td>Accel./decel. time</td></tr><tr><td>short</td><td>open</td><td>2nd. accel./decel. time</td></tr><tr><td>open</td><td>short</td><td>3rd. accel./decel. time</td></tr><tr><td>short</td><td>short</td><td>4th. accel./decel. time</td></tr></table>	between 「I5」&「G」	between 「I6」&「G」	Accel./decel. setting	open	open	Accel./decel. time	short	open	2nd. accel./decel. time	open	short	3rd. accel./decel. time	short	short	4th. accel./decel. time	4 9																			
between 「I5」&「G」	between 「I6」&「G」	Accel./decel. setting																																			
open	open	Accel./decel. time																																			
short	open	2nd. accel./decel. time																																			
open	short	3rd. accel./decel. time																																			
short	short	4th. accel./decel. time																																			

*1) Factory setting

No.	Parameter title	Description	Order of display
58	Acceleration mode selection	<p>You can select among linear, curved(S-shaped) accel./decel.</p> <p>● L In Linear*1 ● 5-1 S-shaped ① ● 5-2 S-shaped ②</p>  <p>Normal accel./decel. mode... accel./decel. time is linear. Larger inclination at larger torque, smaller inclination at smaller torque. S-shaped curve between F1 and F2. Smooth accel./decel.</p> <p>- When you select 5-1 S-shaped①, the Inverter follows to the preset accel./decel. time under the range of base freq., but shows smaller inclination at higher frequency than base freq.</p>	5 7
59	Deceleration mode selection		5 8
60	Monitor mode selection	<p>You can select the type of output displayed at 4-digit LED per below value is multiplied by magnification of 64 Display magnification</p> <p>● 0-F : Output freq.*1 ● CUr : Output current</p> <p>● 5-F : Preset freq. ● dC-U : DC voltage at the converter</p>	5 9
61	Display magnification	<p>You can set the magnification and you can display such a frequency of the motor speed or production line speed. For example, if you set to 30.0, synchronous speed of the 4-pole motor will be displayed.</p> <p>※If you change this parameter, all the displayed value parameter relating frequency represent the value multiplied by display magnification.</p>	6 0
62	Frequency meter adjustment	<p>You can calibrate the frequency meter.</p> <p>Adjust with Δ ▽ so that the meter reads full scale.</p>	6 1
63	Full scale frequency adjustment	<p>You can select the frequency for full scale of the frequency meter. Factory setting shows the full scale at 60Hz. Please adjust when you operate at more than 60Hz.</p>	6 2
64	「FOUT」 selection	<p>You can select the frequency signal at 「FOUT」 terminal.</p> <p>● dIG Digital frequency counter output ● ANA Analog frequency meter output*1</p>	6 3
65	Comparative frequency A	<p>You can set the frequency you want to detect when you select 51 Output signal selection to CE-F (Check frequency).</p> <p>- Activates 「ON」 (「O1」 and 「COM1」) when the output frequency exceeds 65 Comparative frequency① and 「OFF」 when it gets lower than 66 Comparative frequency②.</p>  <p>「O1」-「COM1」 • A ≥ B 「O1」-「COM1」 • A < B</p>	6 4 6 5
66	Comparative frequency B		


*1) Factory setting

No.	Parameter title	Description	Order of display
B0	Trip causes clearance	<p>You can clear the trip causes.</p> <p><How to clear></p> <p>① Set to YES with (Δ) and turn off the power.</p> <p>② Clear by turning the power on after LED disappear and LED shows CLR.</p> <p>③ To operate the Inverter again, turn power off then on again.</p>	7 8
B1	Trip cause ①	<p>The Inverter memorizes causes of last 5 trips.</p> <p>- Refer to Chapter「5.8 Monitoring」 for the contents of the display.</p>	7 9
B2	Trip cause ②		8 0
B3	Trip cause ③		8 1
B4	Trip cause ④		8 2
B5	Trip cause ⑤		8 3
B6	Parameter initialization	<p>You can initialize all parameter to the factory setting.</p> <p><How to initialize></p> <p>① Set to YES with (Δ) and turn off the power.</p> <p>② Initialize by turning the power on after LED disappear and LED shows ----.</p> <p>③ To operate the Inverter again, turn the power off then on again.</p>	8 4
B7	Motor selection	Set the motor capacity and pole numbers.	8 5
B8	Do not use.		8 6
-	Parameter lock	<p>You can 「lock」 the preset parameters.</p> <ul style="list-style-type: none"> ● NO No lock.*1 ● ALL Lock all the parameter. ● PRG Lock the parameters unnecessary to set. <p>- If you select PRG, you can only set the parameter chosen with 「Number of selectable parameter」</p> <p>- Refer to 「How to lock the parameter」.</p>	

*1) Factory setting

7.2 Megger test


- (1) Please perform the megger test only to the main circuit per the following procedure.
Please do not apply to the control circuit.
- (2) If you perform this test to the external circuit, please take off all the terminals so that the test voltage may not be applied to the Inverter.
- (3) Please make sure that the megger test is more than $1\text{M}\Omega$ measured with DC 500V class insulation tester.



7.3 Selection of meters

If you test, please use the following meters and circuit. Please note that test data may differ based on the different meters since the primary and the secondary voltage and current of the Inverter contain higher harmonics.

(Test Point / Meter)



8.1 Protective functions


DV707H Series have following classified protective functions;

- ① Avoid the trip but with no warning indication.
- ② Shut off the Inverter output with warning indication.
- ③ Trip for protection. (Trip signal cannot be held when you turn off the power.)


Type	Protective function LED display	Content of protection or possible cause	Corrective action
①	Overcurrent stall prevention [] (no indication)	Prevent the trip by making acceleration time longer when Motor current exceeds [56 Current limit activation point] during acceleration or running constant speed. - You can adjust the activation level through [56 Current limit activation point].	Extend acceleration time or reduce the load inertia.
	Overvoltage stall prevention [] (no indication)	Prevent the trip by making deceleration time longer when DC converter voltage exceeds 390V during deceleration. - You can adjust deceleration time with [57 Stall deceleration magnification].	Correct the motor load or extend deceleration time.
②	Warning of the lack of input voltage Instantaneous power failure protection [L]	Shut off the output when the converter voltage becomes lower than 400V(DC): *1 Inverter sees this as [Instantaneous power failure]. Also the control circuit will be reset when the converter voltage gets lower than 150V. If voltage recovers before the reset of control circuit, the Inverter resume operation automatically. *2	Check the wiring of the power or power condition.
	Reverse run prevention [F.E.U.P]	Prevents reverse run even when rev. signal is entered, if you select this function. *3	Check reverse run signal.
	Automatic restart prevention [F.P]	Prevents automatic restart after power-on, or power resumption after power failure, or trip resetting in the case run command is entered. *2	Enter stop command then enter run command.
③	Overcurrent trip [O.C] (at normal run) [O.C - U] (at acceleration) [O.C - d] (at deceleration)	Trips when the output current exceeds 200% of the rated current. Lower input voltage or too large GD ² , shorter acceleration/deceleration time, load short circuit or grounding.	Verify proper input voltage. Extend acceleration/deceleration time. Resize Motor/Inverter system Check wiring.
	Regenerative overvoltage trip [O.U]	Trips when the converter voltage exceeds 800V due to regenerative energy. Shorter deceleration time.	Extend deceleration time.
	Power on overvoltage trip [E.O.U]	Trips when the converter voltage exceeds 800V on power-on. Capacity of the power factor correction reactor set up on the input side of the Inverter is too large.	Correct reactor capacity.
	Overload trip (Electronic thermal) [F.H.r]	Trips when motor current keeps exceeding the setting value of [79 Electronic thermal], by interpreting this status as overload.	Verify the overload factor to reduce the load. Change the running pattern. Resize Motor/Inverter system Check wiring.

8.2 Measures to eliminate external noise

- Please separate cables of the control circuit and the power line.



- If you use longer cables for the control circuit, external noise may come in from these cables which may cause the malfunction of the Inverter. In this case, it is recommended to use [Data Line Filter] and make turns of cable around this filter. (Please install this Filter as close to the Inverter as possible.)



8.3 Measures to eliminate R.F.I.

- The radio noise is due to the electromagnetic wave radiated from the Inverter or the power supply. The influence of the radio noise grows by frequency band of 10MHz or less (especially the medium frequency band), in the region where the radio wave is weak.

< How to suppress >

Set up the noise filter in the power supply side of the Inverter and shield the output side of the the Inverter. By this you can expect some suppression of the noise. Connect OUT-side of the filter to the power source and IN-side to the Inverter.

